

Technical Sheet

Endurance GSM Capturs

- GPS
- GSM / LTE Network
- 3-axis accelerometer
- Up to 5 years battery life
- 2 positions / day sent
- IP67
- Replaceable battery
- Web / mobile platform

For additional information
To request a quote
To request an appointment

Contact us now
contact@capturs.com
www.capturs.com

GPS tracker **Endurance GSM**

Use cases

GPS tracker for global monitoring of large tools, equipment or assets over long periods/distances. Supply chain tracking. Theft prevention.



Connectivity

Operating Band

Cat M1: B1/ B2/ B3/ B4/ B5/ B8/ B12/ B13/ B18/ B19/ B20/ B25/ B27/ B28/ B66/B85

Frequency

EGPRS 850 / 900 / 1800 / 1900 MHz

Countries included in the SIM Europe subscription:

Austria, Belgium, Bosnia and Herzegovina, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, French Guiana, Germany, Gibraltar, Greece, Hungary, Iceland, Ireland, Italy, Kosovo, Lithuania, Luxembourg, Malta, Mayotte, Netherlands, Norway, Poland, Portugal, Réunion, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, Ukraine, United Kingdom.

Countries included in the World SIM subscription:

Afghanistan, Albania, Algeria, Angola, Anguilla, Antigua and Barbuda, Argentina, Armenia, Aruba, Australia, Austria, Azerbaijan, Bahamas, Bahrain, Bangladesh, Barbados, Belarus, Belgium, Belize, Benin, Bermuda, Bhutan, Bolivia, Bonaire, Bosnia and Herzegovina, Botswana, Brazil, British Virgin Islands, Brunei, Bulgaria, Burkina Faso, Burundi, Cambodia, Cameroon, Canada, Cape Verde, Cayman Islands, Central African Republic, Chad, Chile, China, Collectivity of Saint Martin, Colombia, Congo, Costa Rica, Cote d'Ivoire, Croatia, Cyprus, Czech Republic, Democratic Republic of the Congo, Denmark, Dominica, Dominican Republic, Ecuador, Egypt, El Salvador, Equatorial Guinea, Estonia, Faroe Islands, Fiji, Finland, France, French Guiana, French Polynesia, Gabon, Georgia, Germany, Ghana, Gibraltar, Greece, Greenland, Guam, Guatemala, Guinea, Guinea-Bissau, Guyana, Honduras, Hong Kong, Hungary, Iceland, India, Indonesia, Ireland, Isle of Man, Israel, Italy, Jamaica, Japan, Jersey, Jordan, Kazakhstan, Kenya, Kosovo, Kuwait, Kyrgyzstan, Laos, Latvia, Liberia, Libya, Liechtenstein, Lithuania, Luxembourg, Macau, Madagascar, Malawi, Malta, Martinique, Mauritania, Mauritius, Mayotte, Mexico, Moldova, Mongolia, Montenegro, Montserrat, Morocco, Mozambique, Myanmar, Nauru, Nepal, Netherlands, Netherlands Antilles, New Zealand, Nicaragua, Niger, Nigeria, Northern Mariana Islands, Norway, Oman, Pakistan, Palestinian National Authority, Panama, Papua New Guinea, Paraguay, Peru, Philippines, Poland, Portugal, Puerto Rico, Qatar, Republic of North Macedonia, Réunion, Romania, Russia, Rwanda, Saint Helena Ascension and Tristan da Cunha, Saint Kitts and Nevis, Saint Lucia, Saint Vincent and the Grenadines, Samoa, Saudi Arabia, Senegal, Serbia, Seychelles, Sierra Leone, Singapore, Slovakia, Slovenia, South Africa, South Korea, Spain, Sri Lanka, Suriname, Swaziland, Sweden, Switzerland, Taiwan, Tajikistan, Tanzania, Thailand, The Gambia, Timor-Leste, Togo, Tonga, Trinidad and Tobago, Tunisia, Turkey, Turks and Caicos Islands, Uganda, Ukraine, United Kingdom, United States, Uruguay, Uzbekistan, Venezuela, Vietnam, Yemen, Zambia.

Geolocation

GNSS

u-blox All-in-One GNSS receiver for GPS

Ground accuracy: < 6m

Motion detection using a 3-axis accelerometer.

Certifications

FCC, Verizon, PTCRB, AT&T, T-Mobile, CE

Hardware interface

- Central button: checks operating status and triggers an alert
- ON/OFF switch: internal only
- LTE antenna: internal only
- GNSS antenna: internal only

General specifications

Dimensions

85 × 49 × 30mm

Weight

140g

Sensors

3-axis accelerometer
GPS

Operating temperatures

-20°C ~ +60°C

Water and dust resistance

IP67

Battery

3 CR123A lithium batteries, 1400mAh
(replaceable battery pack)

SIM

3FF (multi-operator SIM card supplied,
first activation required)

Alerts

SMS
Email

Default configuration

2 positions / day

Two locations are provided each day. If you wish to increase or decrease this number, please contact us for remote configuration according to the subscription you have chosen.

Booster mode

There is also a booster mode, which can be activated by contacting us (to recover tools following a theft, for example). This mode provides a location every 5 minutes when the device is in motion. It will be triggered the next time data is transmitted. Please note that using this mode reduces the overall autonomy of the device.

Battery life

Use	Average battery life
1 position / day	5,8 years
2 positions / day	3,2 years
3 positions / day	2,2 years

Battery life is provided for reference only and may vary according to use, environmental conditions and connectivity.

Options

- Batch configuration of alerts from a CSV file
- Temperature sensor
- Additional mounting options not supplied

User interface

Synchronisation

Data automatically recorded with the Capturs cloud.

Export format

.GPX
.CSV
.PDF

Alerts

Zone entry, zone exit, absence, low battery, button (long press)

API

Use the raw data sent by the Capturs GPS tracker on a third-party system (ERP, mapping system, CRM, etc.) using the Capturs API.

Web / mobile interface

Web platform <https://connect.capturs-systems.com/>

Free Capturs application available on App Store (iOS) and Google Play (Android)

Mounting options

Double-sided adhesive tape is included with purchase.

There are several options for mounting the device: a mounting bracket, a clamp, screws, a neodymium magnet, or double-sided adhesive tape. For more information on accessories, please contact us.

Installation recommendations and optimisation

Environment

Do not place the GPS tracker where it could be obstructed by metal or carbon fibre walls, as these could interfere with or block the radio frequency signals.

If your equipment is used in harsh conditions, the GPS tracker can be installed in a protected area, but never under metal or carbon fibre.

Make sure that the surface on which the GPS tracker is installed is flat and clean to ensure a solid and durable fixing.

Avoid installing the GPS tracker on parts that are often subject to shock or vibration.

Do not place the GPS tracker where it could accumulate a lot of water.

Positioning

To ensure excellent network coverage, position the GPS tracker at the highest point on the equipment.

It is important that the GPS tracker has a clear view of the sky.

The GPS tracker must be installed in a vertical position. If it is not possible to install the GPS tracker vertically, avoid installing it upside down.